

Cobble Systems' Fast and Efficient Installation

EXTERIOR APPLICATIONS



Prepare base as you would for a standard paver installation.

Lay sheets down on prepared base.



Run compactor over stone surface and wet application prior to filling joints.



Apply Cobble Systems™ water permeable silica epoxy mortar (SEM)*. Joints can also be filled with other materials such as coarse sand, stabilized sand or fine gravel.



Wet stones thoroughly. Squeegee Cobble Systems™ silica epoxy mortar (SEM)* over entire stone surface.



Broom lightly to remove excess mortar. Allow mortar to set and cure.



Enjoy your Cobble Systems™ application for years to come!

INTERIOR APPLICATIONS



Use 3/4" cobble for indoors. Apply sheets over suitable adhesive on subfloor or concrete. Wet and fill with Cobble Systems™ silica epoxy mortar (SEM)*. Squeegee and broom lightly.

**Prior to installation please refer to Cobble Systems™ silica epoxy mortar (SEM) instructions on package.*



*The Evolution of
European Cobble*

DISTRIBUTED BY

www.cobblesystems.com

Orlando, Florida
Toll Free: 877 238-8663
Local: 407 487-8663
Fax: 407 841-4426

Toronto, Ontario
Toll Free: 866 899-8801
Local: 416 650-9762
Fax: 416 739-9506